

# PLEASE READ THIS TOPCARD FIRST!

Now that you've received your Touch System, you're probably eager to have it up and running. Before you proceed, please read, understand and execute the following procedures. Doing so can save you time, confusion and frustration and ensure that your Touch System operates at peak efficiency from the moment that you switch it on. If you have any concerns please consult your dealer first.

## 1 FIND THE BEST LOCATION

It is important to prepare a site with proper working conditions before setting up your system.



Computers prefer normal room temperatures (10°-35°C / 50°-95°F). **Avoid locations with direct sunlight, windows, glare, heat sources (e.g. radiators) and areas that are cold in the winter.**



Site your system near a reliable electrical outlet. **Avoid using multiple adapters or extension cables to reduce confusion and the risks of system overload.**



Computers are magnetic devices. **Do not place objects that generate magnetic fields (e.g. unshielded speakers) near disks (e.g. CDs, DVDs, etc.) and drives.**

## 2 UNPACK YOUR SYSTEM

Make sure everything is present and accounted for before you turn on your Touch System.

Open the boxes carefully to avoid damaging their contents and the containers. Touch Systems ship in environmentally-friendly boxes with recyclable foam packaging.

Examine the contents of each carton thoroughly to verify that the system is complete and in good condition. **Report damage or missing items to your dealer immediately.**


All items returned to your dealer should be sent using the original boxes to ensure maximum protection in transition and compliance with the warranty.

Save all packing materials (packing slip, foam or anti-static bags) in case you have to repack and move the system later.

Touch Systems are packed in one or more boxes. Confirm that your computer includes the necessary software/documentation, licenses, manuals, and accessories (e.g. power cables).



**IMPORTANT: DO NOT REMOVE THIS STICKER! Serial Number Label:** The case of your Touch System has been affixed with a label with a 7- or 8-digit serial number. This label is critical for warranty tracking (i.e. repairs or servicing) purposes--avoid removing or tampering with it.




EXAMPLE OF A TOUCH SYSTEM SERIAL # LABEL

## 3 CONNECT SYSTEM POWER

Colour-coded ports and connectors make it simple to connect your Touch System quickly.

Most ports on the computer's back panel are colour-coded to match their devices' connectors. Please refer to the motherboard manual for details. **Exceptions include:**

**SYSTEM:** With the system's power switch turned OFF, connect the system power cord cable to the main power supply.




## 4 CONNECT MONITOR POWER

Colour-coded ports and connectors make it simple to connect your Touch System quickly.

**MONITOR:** Insert the monitor signal cable into the monitor port of the system's rear panel.

Connect the monitor power cable to the main power supply. **Do not modify the monitor or system power plugs!**



## 5 BEFORE TURNING ON YOUR SYSTEM

Some precautions you'll want to observe before powering on your Touch System.

- 1 Ensure that system power is initially turned OFF.
- 2 Check all cables and connections, particularly the base unit and monitor's connectors.
- 3 Ensure that the monitor's signal cable is correctly and firmly plugged into the base unit.
- 4 Mouse, keyboard and other devices (e.g. speakers, external drives) should be firmly plugged into their appropriate connections.
- 5 Most Touch Systems have an optical drive installed. Because it uses lasers, **do NOT open or take apart this drive.** There are no serviceable parts inside; and, more importantly, exposure to laser radiation is harmful to your health (especially your eyes).
- 6 Touch Systems may use lithium batteries. There is a risk of fire, explosions, or burns if these batteries are handled incorrectly. **Please do not recharge, disassemble, heat, or incinerate a lithium battery.** Replace the battery with an identical or equivalent type lithium battery. Discard lithium batteries according to Canadian dispositions.

## 6 STARTING YOUR SYSTEM

You are now ready to switch on your Touch System for the first time. Turn on the Main Power Switch located on the back panel (if present on your case).

Press the Power-On Button located on the front panel.

After powering up, the operating system will prompt you for its license number. Type it in and press the **[Enter]** key. If you have followed the instructions on this sheet correctly, you can enjoy many productive years of computing with your Touch System!

**NEED MORE INFORMATION ON YOUR TOUCH SYSTEM? DOWNLOAD THE USER MANUAL BY ENTERING THE LINK BELOW INTO THE LOCATION OF YOUR INTERNET BROWSER.**